

## RECOGNIZING THE NEW SL/T5R ENERGY STAR PRINTER



Look for the *Energy Star*® logo on the lower left front of the printer:

The model number shown on the data plate on the rear of the machine is changed:

**Model #** – SL/T5R for all printers **Version #** – same as previous T5r model #



The serial number will include “ES” in the second and third position:

<u>Column # of Digits</u>	<u>Description</u>
1-1	1 Plant Code 4 = IRV 5 = SXN 6 = HOL 7 = CMP
2-3	2 <b>ES (RoHS+Energy Star)</b>
4-5	2 Last 2 digits of current year
6-7	2 Week number (01 – 52)
8-10	3 numeric sequence (001 – 999)